




# COOKTOP PARTS

For Models: RS675PXGB4, RS675PXGQ4, RS675PXGZ4  
(Black) (White) (Almond)

30" DROP-IN  
ELECTRIC OVEN  
SELF CLEAN



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------


NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	LIT3191799	Literature Parts
	LIT3191537	Installation Instructions
	LIT3192845	Use & Care Guide
	LIT3191638	Tech Sheet
	LIT3191638	Safe Cooking Tips
2	3192459	Burner Box
3	3192330	Bracket, Mounting
	3400843	Screw, 8-18 x 3/8
4		Cooktop
	3191169	Almond
	3191168	White
	3191167	Black
5	3192575	Clip, Mtg. (4)
6		Panel, Control
	3191230	Almond
	3191229	White
	3191228	Black
7		Switch, Infinite
	3191471	Use W/6" Surface (Blue Shaft)
	3191473	Use W/8" Surface (Red Shaft)
	3400855	Screw, 8-32 x 1/4
8	3191491	Light, Indicator
11		Pan, Surface
	3195208	6" Pan
	3195209	8" Pan
12		Element, Surface
	8053266	6" Burner
	8053268	8" Burner
14		Knob, Control
	3196232	White
	3196233	Almond
	3196231	Black
15	3183956	Seal, Switch Shaft (4)
18		Trim, Extension
	3192103	White
	3192104	Almond
	3192102	Black
19	3195917	Clip, Element

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OVEN PARTS

For Models: RS675PXGB4, RS675PXGQ4, RS675PXGZ4  
(Black) (White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OVEN PARTS

For Models: RS675PXGB4, RS675PXGQ4, RS675PXGZ4  
(Black) (White) (Almond)

Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.		
2		Trim, Side (Right Hand)
	4450845	White
	4450846	Almond
	4450844	Black
	4449747	Screw (Left Hand)
	4450848	White
	4450849	Almond
	4450847	Black
	4449747	Screw
3		Hinge Receiver
	4454664	Left Hand
	4454665	Right Hand
4	4448520	Bumper, Door
7	4455190	Top Chassis
	4449809	Screw
9	4452158	Tube, Vent
	4449154	Screw
10	4452165	Lens, Light
11	4452368	Oven Light Assy
12	4452166	Bulb, Light

Illus. No.	Part No.	DESCRIPTION
14	4451740	Frame, Front
	4449040	Screw
	4450118	Nut
15	4455382	Gasket, Door
19	4451478	Support, Insulation
	4449809	Screw
21		Rail, Side
	4450579	Right Side
	4450580	Left Side
	4448444	Grommet
	4449154	Screw
22	4451896	Latch Assembly
23	4452224	Solenoid
24	4452312	Micro Switch N.C.
	4449154	Screw
25	4454691	Side, Chassis (R.H. & L.H.)
	4449809	Screw
26	4452234	Back, Chassis
	4449809	Screw
27		Liner, Oven (Not serviceable)
28	4451426	Micro Switch
29	4451665	Sensor
	4449154	Screw

Illus. No.	Part No.	DESCRIPTION
30	4451537	Spring, Latch
37	4451442	Thermostat (TOD) (Temp.) SPST
43	4451398	Base, Chassis
49	4448933	Retainer, Gasket
	4449154	Screw
50	4451747	Cover, Back
	4449809	Screw
53	4449845	Support, Bracket
	4449809	Screw
	4449809	Screw
55		Trim, Bottom
	4448478	White
	4448862	Almond
	4448477	Black


## FOLLOWING PARTS NOT ILLUSTRATED

### INSULATION

4449316	Insulation, Wrap
4450365	Insulation, Back

# CONTROL PANEL PARTS

For Models: RS675PXGB4, RS675PXGQ4, RS675PXGZ4  
(Black) (White) (Almond)




Illus. No.	Part No.	DESCRIPTION
1	4452845	Control Panel Assy. White
	4452846	Almond
	4452844	Black
		W/Membrane Switch
	4449745	Screw
2	4451034	Gasket, Control Panel
3	4453193	Microcomputer
	4449745	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OVEN DOOR PARTS

For Models: RS675PXGB4, RS675PXGQ4, RS675PXGZ4  
(Black) (White) (Almond)



**Illus. Part**  
**No. No. DESCRIPTION**

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1 4451719 Door Liner  
2 4454947 Hinge, Door  
4449743 Screw  
3 4449259 Glass, Inner  
4 4451722 Insulation, Door  
7 4449263 Glass, Inner (2)

**Illus. Part**  
**No. No. DESCRIPTION**

9 4451668 Retainer, Glass  
4449809 Screw  
13 4448855 White  
4448856 Almond  
4448854 Black  
14 4450813 Bracket, Handle  
4451040 Screw  
15 4452066 White  
4452067 Almond  
4452065 Black


**Illus. Part**  
**No. No. DESCRIPTION**

19 4450362 Shield, Heat  
4449809 Screw  
20 4451671 Retainer, Glass  
4449809 Screw  
21 4451674 Seal, Door Top  
23 4450864 White  
4450865 Almond  
4450863 Black  
24 4455257 Glass, Inner

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# INTERNAL OVEN PARTS

For Models: RS675PXGB4, RS675PXGQ4, RS675PXGZ4  
(Black) (White) (Almond)




Illus. No.	Part No.	DESCRIPTION
2	4452154	Element, Broil
	4449154	Screw
3	3147563	Grill, Broiler
4	3147845	Pan, Broiler
6	4448717	Rack, Oven
7	4452153	Element, Bake
	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TOP VENTING PARTS

For Models: RS675PXGB4, RS675PXGQ4, RS675PXGZ4  
(Black) (White) (Almond)



Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	4451759	Vent, Exhaust
	4449040	Screw, 8-18 x 3/8
2	4455178	Elbow, Vent Top
3	6610168	Blower
	4455191	Plate, Blower Service
4	4451758	Block, Foam
5	4455177	Elbow, Vent Bottom
6	4451789	Plate, Service
11	4449868	Block, Terminal
	3400016	Screw
13	4448549	Vent, (Control Panel)
	4450038	Screw
14		Side, Control Compt.
	3191832	Right
	3191833	Left
	4449809	Screw
15	4452244	Back, Control
	4449809	Screw
20	3191842	Cover, Rear

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OPTIONAL PARTS

For Models: RS675PXGB4, RS675PXGQ4, RS675PXGZ4  
(Black) (White) (Almond)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

## PAINT, TOUCH-UP (1/2oz.)

	72017	White
	261869	Cord Brown
	72032	Black

## PAINT, SPRAY

	350930	White
	261900	Citrine White
	830864	Black

## ADHESIVE

	591014	Adhesive Loctite (1/3 oz.)
	482338	Sealer, Silastic (3 oz.)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

## SPLICING WIRES--25FT.

### LENGTH

	242828	Wire (12 Ga. 150 c Black)
	242820	Wire (14 Ga. 150 c Black)
	242821	Wire (14 Ga. 150 c Blue)
	242822	Wire (14 Ga. 150 c Brown)
	242830	Wire (14 Ga. 200 c Brown)
	242823	Wire (14 Ga. 150 c Green)
	242824	Wire (14 Ga. 150 c Orange)
	242829	Wire (12 Ga. 150 c Red)
	242825	Wire (14 Ga. 150 c Red)
	242831	Wire (14 Ga. 200 c Red)
	242826	Wire (14 Ga. 150 c White)
	242827	Wire (14 Ga. 150 c Yellow)
	242832	Wire (14 Ga. 200 c Yellow)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

## WIRING HARNESS PARTS

	3191220	Harness, Wire (Main)
	4455366	Harness, Wire (Surface)
	4451163	Conduit
	4448664	Clamp
	4449809	Screw
	112432	Nut
	4450800	Screw, Ground
	3192236	Harness, Wire (Infinite Switch)
	3192245	Harness, Wire (Light)
	4454384	Ground, Wire

## Miscellaneous

	814381	Hinge Pin Kit
	4448950	Screw, Install (4)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST